



809 Window Swing Lock Fitting Instructions

Installing a Window Swing Lock

To fit a Window Swing Lock you will require the following tools:

- Drill
- 12.5mm drill bit
- Flat blade screwdriver
- Pencil

If fitting to hardwood, drill 2.5mm pilot holes.

A Close window and select position of Window Swing Lock:

- ▶ Position if fitting a single lock
- ▶ Position if fitting two locks

B Position striker plate flush with the edge of fixed frame ensuring that flat face of striker plate is facing the window. Mark screw holes and screw in position.

C Position lock body on opening frame ensuring a 2mm gap between edge of lock body and striker plate.

NB: Pivot to bottom of lock to access screw holes. Mark position of holes and screw to opening frame.

Additional Information

Operation - Swing top section of lock body over peg and screw bolt clockwise with the key provided. To unlock screw bolt anti-clockwise and swing top section of lock body clear of peg.

Safety Tips - For child safety fit ERA Window Restrictor Ref: 720, to restrict full opening.

Security Tips - Fit swing lock at top and bottom of window for maximum security and draught reduction. Always close and lock windows, remove key from locks when leaving the home.

