



Suitable for  
wood or glass door  
from 12mm to 55mm

**When using this Back to Back Fixing pack you do not require any fixings supplied with the Pull Handle**

1- Securely fasten the short screw end of the two fixing bolts (1) into both ends of the Tubular Handle fixing points.

2- Slide the solid bushes (with the round hole) (2) over the fixing bolts.

These bushes should be the same diameter as the Tubular Handle or Tubular legs of 'T' Pull Handle .

3- Slide one plastic washer (3) over each of the fixing bolts (optional when fitting to Wood Doors).

**These are essential when fitting to Glass Doors**

4- Slide the plastic sleeve (4) over both fixing bolts.

**These are essential when fitting to Glass Doors** and not required for Wood Doors.

5- Insert the Pull Handle with the assemblies into and through the existing / prepared holes in the door.

(As recommended within the Pull Handle Instructions)

This side, - the Fittings are not able to be removed therefore it is recommended to fit to the external side of the door, if required.

6- If the projection of the bolt from the face of the door is more than 30mm, it may be necessary to shorten the bolts using a metal cutting saw blade.

7- Slide over the plastic washer (3) **Essential when fitting to Glass Doors** but optional when fitting to Wood Doors.

8- Insert the top projecting screw into the Tubular Handle and using the tool (6) insert into the small hole within this bush (5) and turn until the bolt is engaged a small amount into the Pull Handle . Repeat this for the bottom fixing.

9- Continue to secure the Pull Handle to the door faces by turning the bush (5) progressively top and bottom until the Pull Handles are securely fastened to the door.