



SLIKSEAL FITTING INSTRUCTIONS

Please read and familiarize yourself with these instructions **BEFORE** attempting to fit Slikseal

1. The door/window should be closed and fastened in its usual position during fixing.
2. Cut short length to size with fine tooth saw and nail in position at the top of the door frame with the pile pressing gently against the door face.
3. Next, cut the two long side pieces to length and nail into position. NB Open and close the door several times during fitting to ensure that the door exerts an even contact pressure at all points on the brush pile.

TOOLS REQUIRED

Pencil, fine tooth saw and hammer.