



## **FOAM INTERNAL DOOR DOUBLE DRAUGHT SEAL**

- 1) Measure width of the door.
- 2) Cut the draught excluder to this size.
- 3) Slip end of the Draught Excluder under the open door and slide all the way to the end.